



**Make:** Mitsubishi  
**Model:** Lancer/Evolution 8  
**Year:** 2003-04

## Alarm

Function	Color	Location
Constant 12 volts	WHITE	IGNITION SWITCH HARNESS
Ignition 12 volts	BLACK/WHITE	IGNITION SWITCH HARNESS
Starter	BLACK/YELLOW	IGNITION SWITCH HARNESS
Dome Light	WHITE (-)	WHITE CONNECTOR BOTTOM OF FUSE BOX
Trunk Pin Switch	GREEN/ORANGE (-)	LIGHT IN TRUNK
Parking Lamp	GREEN/WHITE (+)	WHITE CONNECTOR BOTTOM OF FUSE BOX
Power Lock	PURPLE	DRIVER KICK PANEL #201
Power Unlock	LT GREEN	DRIVER KICK PANEL

#201 See Negative Pulse Door Lock Diagram. Information Courtesy Of Installer!! Any Additional Information Appreciated!!

## Accessories

Function	Color	Location
Window Up		
Window Down		
Ign Key Warn		
Trunk Release		
OEM Horn	BLUE/RED (-)	STEERING COLUMN
Headlights		
OEM Alarm Arm		
OEM Alarm Disarm		

Information Courtesy Of Installer!! Any Additional Information Appreciated!!

## Remote Start

Function	Color	Location
Tach Signal	ORANGE @ IGNITOR # 1	CYLINDER
Ignition #2	BLUE/BLACK	IGNITION SWITCH HARNESS
Ignition #3		
Accessory		
Neutral Safety		
Brake Light	GREEN (+)	AT SWITCH ABOVE PEDAL
Reverse Light		
Rear Window Defrost		

Only Evolution VIII Models Have Been Shown To Have An Immobilizer. Information Courtesy Of Installer!! Any Additional Information Appreciated!!

## InterConnect Harness

Function	Part #	Available	Location
StrInt,+12,Gnd,Ign		no	
Horn Honk		no	
Lock & Unlock		no	
Light Flash		no	
Dome Light		no	
Trunk Switch		no	
AL-100 / VIP-4000		no	
Remote Start		no	



**Make:** Mitsubishi  
**Model:** Lancer/Evolution 8  
**Year:** 2003-04

#### AL100/VIP-4000

##### Function

RKE Module

Motor Lock

Motor Unlock

Drv Door Unlock

OEM Relays

Addon Security Type

**Color**

**Location**

#### Tech Notes

**Driver**

**Passenger**

**Size**

**Location**

(+)

Front

(-)

(+)

Rear

(-)