



Make: Mitsubishi
Model: Lancer
Year: 2002

Alarm

Function	Color	Location
Constant 12 volts	WHITE	IGNITION SWITCH HARNESS
Ignition 12 volts	BLACK/WHITE	IGNITION SWITCH HARNESS
Starter	BLACK/YELLOW	IGNITION SWITCH HARNESS
Dome Light	WHITE (-)	WHITE PLUG BOTTOM OF FUSE BOX
Trunk Pin Switch	GREEN/ORANGE	AT LIGHT IN TRUNK
Parking Lamp	GREEN/WHITE (+)	WHITE PLUG BOTTOM OF FUSE BOX
Power Lock	YELLOW	DRIVER KICK PANEL #201
Power Unlock	GRAY	WHITE PLUG *
#201- See Negative Pulse Door Lock Diagram. Door Lock Also Found As: PURPLE (-)		Side Of Door Unlock Found As : LT GREEN (-)
Fuse Box. Information Courtesy Of Installer!! Any Additional Information Appreciated!!		

Accessories

Function	Color	Location
Window Up		
Window Down		
Ign Key Warn		
Trunk Release		
OEM Horn	BLUE/RED (-)	STEERING COLUMN
Headlights		
OEM Alarm Arm		
OEM Alarm Disarm		
Information Courtesy Of Installer!! Any Additional Information Appreciated!!		

Remote Start

Function	Color	Location
Tach Signal	ORANGE @ IGNITOR # 1	CYLINDER
Ignition #2	BLUE/BLACK	IGNITION SWITCH HARNESS
Ignition #3		
Accessory		
Neutral Safety		
Brake Light	GREEN (+)	AT SWITCH ABOVE BRAKE PEDAL OR *
Reverse Light		
Rear Window Defrost		
* BLACK PLUG IN DRIVERS KICK PANEL.		

InterConnect Harness

Function	Part #	Available	Location
StrInt,+12,Gnd,Ign		no	
Horn Honk		no	
Lock & Unlock		no	
Light Flash		no	
Dome Light		no	
Trunk Switch		no	
AL-100 / VIP-4000		no	
Remote Start		no	



Make: Mitsubishi
Model: Lancer
Year: 2002

AL100/VIP-4000

Function

RKE Module
Motor Lock
Motor Unlock
Drv Door Unlock
OEM Relays
Addon Security Type

Color

Location

Tech Notes

Driver

	Passenger		Size	Location
(+)		Front		RADIO
(-)				
(+)		Rear		RADIO
(-)				